



# HOW TO CONNECT YOUR PREHEATER


TO THE HYDRAULIC POWER STATION?







An electric wire from the combistat.




An electric wire from the burner must be mounted in this connector on the pump station.


This connector should not be used

An electric wire from the combistat must be mounted in this connector of the burner.






An electric wire from the burner must be mounted in this connector on the pump station.




Hydraulic hose P must be mounted on the hydraulic valve on the pump station.





Hydraulic hose P from the preheater must be mounted on the hydraulic valve of the pump station. You can see this is a PS-15 as there are two valves, as there can be two preheaters connected. On a PS-9 there is only one valve.




Hydraulic hose T from the preheater must be mounted here on the pump station. On this PS-15, there are two connections. On PS-9 there is only one.





Diesel connection from the pump station to the preheater.



Diesel connection to the preheater.