



**BMC
30**

MS 13 10-2100

**BMC
30**


HOW TO CHANGE THE NOZZLE

IN THE BM C 30 BEAD GUN?

Borum A/S | Højvangsvej 10, Hadbjerg | DK-8370 Hadsten | Tel. +45 87 613 213 |

info@borum.as | www.borum.as

1. Remove all the beads from the bead gun.
2. Remove the black handle by loosening it.
3. Loosen these two bolts and remove them.



4. You need to remove the top head of the bead gun.



5. To remove the nozzle, you must loosen the bolt.



6. Remove the old nozzle and replace it with a new one.





ANY QUESTIONS?

CONTACT US
SERVICE@BORUM.AS

Borum A/S | Højvangsvej 10, Hadbjerg | DK-8370 Hadsten | Tel. +45 87 613 213 |

info@borum.as | www.borum.as