



BM 2500



PHOTOS MAY SHOW OPTIONAL OR CUSTOMISED EQUIPMENT.

BM 2500 BASIC MACHINE

From city areas to urban and interurban roads, the Borum Master 2500 can handle both smaller jobs and longer road stretches.


The BM 2500 is an agile machine with excellent load abilities. It allows for thermoplastic capacities up to 360 liters, 2-component or Cold Paint capacities of 440 liters and for two colours cold paint also 2 x 220 liters.


Equipped with the new generation of Borum's LineMaster computer, operating the machine is easy and convenient.


The BM 2500 has a one-seat slidable drive and operator section for flexible working on the left or right side.

Easy access and servicing of the machine through large doors to the engine room.

KNOWING THE BM 2500







TECHNICAL SPECIFICATIONS

BM 2500

ENGINE

Manufacturer Kubota

Type Turbo (Diesel)

Cylinder 4 stroke 2400 cm3

RatedPower 44 KW

Approval EU Stage IIIA resp. / US Interim TIER 4

Cooling Water

COMPRESSOR

Compressor Capacity Screw compressor. 1800 L/min @ 10 bar Inte-

grated oil-cooling system. Air-cooler incl. water

separator.

FILLING CAPACITIES

Bead capacity 115 L/170 kg. Pressurized (max 1.2 bars)

Hydraulic tank size 70 L

Fuel tank capacity 2 x 50L

MATERIAL TANK

Material Tank 340 liters or 360 liters for thermoplastic spray,

440 or 2 x 220 liters for cold paint, 440 liters for

2-component

DRIVING PROPERTIES

Steering Dual torque steering

Drive angle 12 degrees / 21% (5000 kg)

Turning radius 4,2 m

TRANSMISSION

Speed 0-15 km/h

Hydrostatic transmission For variable speed, forward/backwards

ELECTRICAL SYSTEM

Electrical system 12 V / 150 Amp

CONTROL UNIT

Borum LineMaster Program up to 99 different line types. Organise

lines in up to 30 marking programs. 8" display. Transfer of daily marking reports. Data about road marking jobs can be accessed online (optional).

DIMENSIONS

Length 4750 mm Height 2520 mm

Width 1180 mm without equipment

ADDITIONAL EQUIPMENT

The additional equipment can be mounted on the machine according to your requirements. They are not necessary for the running of the machine but add to the comfort of the machine driver or to the functionality of the machine.



Ejector filling of bead tank



Sunshade with 1 rotating light



Cruise control



BM Online



Bead alarm mounted on bead gun



Bar with pneumatic lift for mounting warning lights (Comes without lights)



Pre-marking system with paint gun



Cone holder



Pointer turning with steering With hydraulic lifting system



Remote control for BM LineMaster



Air drier for bead tank



Fixed pointerWith hydraulic lifting system



Pre-marking system with paint can



Airknife



Hydraulic broom